



Installation Instruction

Node

For arm and straight pole





Step 1



Step 2

Adjust to desired degree 5°, 10°, 15°...




Step 3




Attentions:


1. The products should be installed and maintained by qualified professionals, could not change the product inner structure or parts by yourself. During the period of installation or maintenance, ensure the electricity is off. Ensure the products earth-wired reliably.
2. Pls do not open the back cover and the wire fixing connectors during usage, meanwhile, make the waterproof treatment of the wire connecting places, otherwise, the product will be damaged by water in due to improper operation;
3. The LED light source should be replaced by manufacturer, service agent or professional qualified technicians;
4. The shell of the product will reach high temperature when using or after using, so it could not be covered with thermal insulation materials



Step 1




Step 2




Step 3

Adjust to desired degree 5°, 10°, 15°...



Step 4



Step 5

